Service Mode

7.1. Self-Diagnosis and Special Mode Setting

7.1.1. Self-Diagnosis Functions

Self-Diagnosis Function provides information for errors to service personnel by Self-Diagnosis Display when any error has occurred.

$U^{\ast\ast},\,H^{\ast\ast}$ and $F^{\ast\ast}$ are stored in memory and held.

You can check latest error code by transmitting [0] [1] of Remote Controller in Service Mode.


Automatic Display on FL will be cancelled when the power is turned off or AC input is turned off during self-diagnosis display is ON.

Error Code	0	Description	Monitor Display	Automatic FL display
U30	Remote control code error	Display appears when main unit and remote controller codes are not matched.	No display	SET * * is remote controller code of the main unit. Display for 5 seconds.
U59	Abnormal inner temperature detected	Display appears when the drive temperature exceeds 70°C. The power is turned off forcibly. For 30 minutes after this, all key entries are disabled. (Fan motor operates at the highest speed for the first 5 minutes. For the remain- ing 25 minutes, fan motor is also stopped.)		U59 U59 is displayed for 30 minutes.
U71	HDMI incompatible error (HDCP incompatible)	The event is saved in memory as well. Display this error when the equipment (com- patible with DVI such as TV, amplifier etc.) connected to the unit by HDMI is incompatible with HDCP. *HDCP=High-bandwidth Digital Content Pro- tection	No display	U71
U72	HDMI connection error (communication error)	This error is displayed when there are any communication problems with the unit and the equipments (TV, amplifier etc.) connected to the unit by HDMI. (or when there is a problem with the HDMI cable)		U72 display disappears when error has been solved by Power OFF/ON of connecting equipment or by inserting/removing of HDMI cable.
U73	HDMI connection error (authentication error)	when authentication error occurs while the equipments (TV, amplifier etc.) are connected by HDMI. (or when there is a problem with the HDMI cable)		U73 U73 display disappears when error has been solved by Power OFF/ON of connecting equipment or by inserting/removing of HDMI cable.
F99	Hang-up	Displayed when communication error has occurred between Main microprocessor (MV2-PLUS (IC60009)) and Timer micropro- cessor (IC7501).		F99 Displayed is left until the [POWER] key is pressed.
H19	Inoperative fan motor	When inoperative fan motor is detected after powered on, the power is turned off automatically. The event is saved in memory.	No display	No display
F00	No error information	Initial setting for error code in memory (Error code Initialization is possible with error code initialization and main unit initialization.)	No display	No display
F34		When initialization error is detected after starting up main microprocessor MV2-PLUS (IC60009), the power is turned off automatically. The event is saved in memory.		No display
F58	Drive hardware error	When drive unit error is detected, the event is saved in memory.	No display	No display

Error Code		Description	Monitor Display	Automatic FL display
UNSUP- PORT	Unsupported disc error	*An unsupported format disc was played, although the drive starts normally. *The data format is not supported, although the media type is supported. *Exceptionally in case of the disc is dirty.	incompatible.	UNSUP PORT
				Display for 5 seconds.
NO READ	Disc read error	*A disc is flawed or dirty. *A poor quality failed to start. *The track information could not be read.	Cannot read. Please check the disc.	NOREAD
HARD	Drive error	The drive detected a hard error.	DVD drive error.	Display for 5 seconds.
ERR				HARD
				₹
				ERR
IR ERR	IR communication error	[IR ERR] is displayed when communication between Timer microprocessor and IR micro- processor fails.	No display	IR ERR
SELF CHECK	Restoration operation	Since the power cord fell out during a power failure or operation, it is under restoration operation. *It will OK, if a display disappears automati- cally. If a display does not disappear, there is the possibility that defective Digital P.C.B. /		SELF ¢ CHECK
PLEASE WAIT	Unit is in termination process	DVD drive. Unit is in termination process now. BYE is displayed and power will be turned off.	No display	PLEASE
				★
				WAIT
UNFOR- MAT	Unformatted disc error	You have inserted an unformatted DVD-RAM or DVD-RW that is unformatted or recorded on other equipment.		UNFOR
				MAT
No PLAY	When there is a viewing restric- tion on a BD-Video or DVD- Video.	Rating password is set.	No display	No PLAY

7.1.2. Special Modes Setting

Item		FL display	Key operation	
Mode name	Description		Front Key	
TEST Mode	*All the main unit's parameters are initialized.	TEST	Press [STOP], [SKIP FWD] and [OPEN/CLOSE] keys simulta- neously for five seconds when power is off.	
Rating password	The audiovisual level setting password is ini- tialized to Level 8.	INIT	Open the tray, and press [SKIP REV] and [PLAY] simultaneously for 5 seconds.	
Service Mode	Setting every kind of modes for servicing. *Details are described in 7.1.3. Service Mode at a glance.	SERV	When the power is off, press [SKIP FWD], [OPEN/CLOSE] and [PAUSE] keys simultaneously for 5 seconds.	
BD-ROM history cleaning	< Persistent Storage> of BD-ROM standard is cleaned. Screen display: [The player's history data has been cleared] is displayed for five seconds.	***** Same display as before execution.	When disc is not in tray. press [STOP] and [POWER] keys simulta- neously for 5 seconds.	
Forced disc eject		The display before execution leaves.	When the power is off, press [SKIP FWD] and [PAUSE] keys simulta- neously for 5 seconds.	



Item		FL display	Key operation
Mode name	Description		Front Key
Demonstration lock/ unlock			 When the power is on (SS mode), press [SKIP FWD] and [OPEN/CLOSE] keys simultaneously for 5 seconds. Note: When a disc is not in tray, this setting is not effective. When the power is on (SS mode), press [SKIP FWD] and [OPEN/CLOSE] keys simultaneously for 5 seconds.
Progressive initialization	The progressive setting is initialized to Inter-	while the tray being locked.	Press [OPEN/CLOSE] key while the tray is being locked. When the power is on (SS mode), press [STOP] and [PLAY] simulta- neously for 5 seconds.

Service Modes at a glance

Service mode setting: While the power is off, press [SKIP FWD], [PAUSE] and [OPEN / CLOSE] simultaneously for five seconds.

Item		FL display	Key operation
Mode name Description			(Remote controller key)
Release Items	Item of Service Mode executing is cancelled.	SERV	Press [0] [0] or [Return] in service mode.
Error Code Display	Last Error Code of U/H/F held by Timer is dis- played on FL. *Details are described in 7.1.1. Self-Diagno- sis Functions.	 ♣□□ *♣ shows U/H/F. □□ shows number. If any error history dose not exist, [F00] is displayed. 	Press [0] [1] in service mode
ROM Version Display	 Region code (displayed for 5 sec.) Main firm version (displayed for 5 sec.) Timer firm version (displayed for 5 sec.) Drive firm version (displayed for 5 sec.) ROM correction version (left displayed) 	1. NO\$% \$: Region of DVD (Example: 1,2) %: Region of BD (Example: A,B) 2. **** 3. **** 4. **** 5. *** * are version displays.	Press [0] [2] in service mode
Drive check	Simple quality of BD/DVD drive.	When BD/DVD drive is OK DRV OK When BD/DVD drive is NG DRV NG *If the date of the present or the trouble occurred time is incorrect, it may be not able to judge correctly.	Press [3] [8] in service mode.
Laser Used Time Indicatoion	Check laser used time (hours) of drive.	I(*****) is the used time display in hour. ILaser used time of DVD/ CD in Playback/Recording mode is counted.	

Item		FL display	Key operation
Mode name	Description		(Remote controller key)
BD/DVD drive last error	BD/DVD drive error code display.	1. Error Number is displayed for 5	Press [4] [2] in service mode.
		seconds.	
		NO **	
		NO **	
		2. Time when the error has occurred	
		is display for 5 seconds.	
		DDhhmm	
		DD : Day	
		hh : Hour	
		mm : Minute 3. Last drive error (1/2) is displayed	
		for 5 seconds.	

		00 : Bad disc	
		03 : Bad disc	
		04 : Bad disc or drive malfunction	
		4. Last drive error (2/2) is displayed	
		for five seconds.	

		5 Error occurring disc type is dis	
		5. Error occurring disc type is dis- played for 5 seconds.	
		DVD-RW	
		DVDRW	
		CD-R	
		CDR	
		0211	
		CD-RW	
		CDRW	
		DVD+R	
		DVDPR	
		DVDPK	
		DVD+RW	
		DVDPRW	
		BD-ROM	
		BDROM	
	1	1	

Item		FL display	Key operation	
Mode name	Description		(Remote controller key)	
		BD-RE		
		BDRE		
		BD-R		
		BDR		
		DVD ROM		
		DVD		
		CD		
		CD		
		RAM (2.6GB)		
		RAM26		
		RAM (4.7GB)		
		RAM47		
		DVD-R		
		DVDR		
		Others		
		MEDIA*		
		* is displayed the respoced value from RTSC.		
		6. Disc maker ID is displayed for 5	n case that the maker cannot be	
		seconds.	dentified, display is black out.	

		7. Factor of drive error (hexadeci-		
		mal) occurring is left displayed.		
		* * + + 🗆 🗆		
		 * * : Error occurring operation code (This is not used) 		
		++: Error occurring disc type		
		0 DVD-ROM		
		1 CD 2 2.6GB DVD-RAM		
		3 4.7GB DVD-RAM 4 DVD-R		
		After 5 Others		

Item		FL display					Key operation	
Mode name Description							(Remote controller key)	
		□□: Error occurring disc situation		on				
		Displa	Disc distinction	With or without	Disc cart- ridge state	Size		
		00		Cartridge With	Not opened	12cm		
		10		With	Not opened	8cm		
		20	OK OK	With With	Opened Opened	12cm 8cm		
			ок	Without	Not opened	12cm		
			ОК	Without	Not opened	8cm		
		60 70	ок ок	Without	Opened Opened	12cm 8cm		
			NG	With	Not opened	12cm		
		90		With	Not opened	8cm		
		A0 B0		With With	Opened Opened	12cm 8cm		
			NG	Without	Not opened	12cm		
			NG	Without	Not opened	8cm		
		E0 F0	NG NG	Without	Opened Opened	12cm 8cm		
		<u> </u>						
250 (1)								
CEC (H) output	Check of the CEC terminal high output of HDMI.		When	the chec	k is OK	_	Press [5] [5] in service mode.	
				CECH	IUK			
			W/hom	the cheel				
			when	the check	K IS NG			
				CECH	ING			
CEC (L) output	Check of the CEC terminal low output of	of When the check is OK CECHOK When the check is NG CECHNG			Press [5] [6] in service mode.			
	HDMI.			7				
				_				
Tray OPEN/CLOSE Test	The DVD drive tray is opened and closed					_	Press [9] [1] in service mode	
	repeatedly.			****	< * *		*When releasing this mode, press	
							the [POWER] button of Remote	
				per of c	pen/close	e cycle	Controller more than 10 seconds.	
Delete the Laser Lised	Laser used time stored in the memory of the	tim	es.			_	Press [9] [5] in service mode.	
Time	unit is deleted.			CLR				
				ULIN				
Delete the Last Drive	Delete the Last Drive Error information stored					1	Press [9] [6] in service mode.	
Error	on the DVD Drive.	CLR						
Delete the Error History	Delete Error History information stored on the						Press [9] [7] in service mode.	
	unit.			CLR				
Error code initialization	Initialization of the last error code held by					7	Press [9] [8] in service mode.	
	timer (Write in F00)			CLR				
Initializa Sanvias	Last Drive Error Error history and Error						Pross [0] [0] in convise mode	
Initialize Service	Last Drive Error, Error history and Error Codes stored on the unit are initialized to fac-						Press [9] [9] in service mode.	
	tory setting.			CLR				
Finishing service mode	Release Service Mode.	Display in STOP (SS) mode.			S) mode.		Press power button on the front	
					panel or Remote controller in ser-			
				****	< * *		vice mode.	